








Title: <b>JM 1500 IGC Installation Into Masonry Surround</b>		Drawing No: <b>M06</b>	
Scale: <b>1:10</b>	Drawn: <b>W. J. Gudzow &amp; Associates</b>	The Fireplace Ltd	
Revision: <b>C</b>	Date: <b>03-06-2008</b>	Phone: (09) 623 6990	
		Fax: (09) 623 6994	
		12 Tawnt Street - Mt. Eden - Auckland - New Zealand	
		www.thefireplace.co.nz email: sales@thefireplace.co.nz	

NOTE: For Air vent requirements please refer to NZS 5261

Place Rock-wool to the rear, sides and top of the Gas Jetmaster (Glue rock-wool using fire cement or mechanical fix using pot rivets with washer to the convector box and gather)

 Rock-wool  
 Masonry Block  
 Hebel Block

NOTE: DO NOT BLOCK OFF AIR FLOW TO FLUE-PIPE CASING







Title: JM 1500 IGC Installation Into Timber Framing		Drawing No: T06	
Scale: 1:10	Drawn: W. J. Cadzow & Associates	The Fireplace Ltd	
Revision: A	Date: 03-06-2008	12 Tawaitee Street - Mt. Eden - Auckland - New Zealand www.thefireplace.co.nz Phone: (09) 623 6990 Fax: (09) 623 6994 email: sales@thefireplace.co.nz	

NOTE: For Air vent requirements please refer to NZS 5261

Please Rock-wool to the rear, sides and top of the Gas Jernister (Gable rock-wool using the Cement or mechanical fix using pot rivets with washer to the convactor box and gather)

NOTE: DO NOT BLOCK OFF AIR FLOW TO FLUE-PIPE CASING



SCALE 1:10

REFERENCE DIMENSION SHEET <i>Jetmaster</i>			
PRODUCT DESCRIPTION		FULL ASSEMBLY 1500 IGC	
DRAWING NUMBER		REFERENCE_1500_IGC	
DRAWING REVISION		00	
DATE	19-Nov-09	SHEET	1 OF 1
THIS IS A REPRESENTATION OF THE PRODUCT REFERENCED ABOVE. NOT TO BE USED AS MANUFACTURING REFERENCE			